









Wall Trim Flashing

Step by step guide on installing wall-trim flashing to your next EPDM Roofing project.

	**Step 1** Thoroughly clean the wall, chase and rubber.
	**Step 2** Apply a thin coat of contact adhesive to the rubber and the wall .
	**Step 3** Once touch dry, starting at the bottom, carefully mate the surfaces together. Smooth by hand and silicone roller.
	**Step 4** Trim membrane.

	**Step 5** Position a piece of 9” Flashing Tape or a Detail Kit as shown and mark the perimeter, allowing an extra 1 cm.
	**Step 6** Apply Primer plus to the marked area using a Scrubber Pad and handle, allow primer to dry.
	**Step 7** Peel back a section of backing paper and, starting from the top, slowly work downwards as shown.
	**Step 8** Apply a gentle heat source to the corner if needed.
	Step 9 Thoroughly roller with Silicone and Penny Rollers.

	
	**Step 10** Insert wall trim into chase and secure at 600mm centres with the supplied fixings. Rawplugs are not needed if a 5.5mm masonry drill bit is used.
	**Step 11** Thoroughly seal chase with Wall Mastic.