Pipe Seal A guide to installing a pipeseal.

RUBBERROOFS, RUBBERROOFS, RUB RUBBERROOFS, RUB RUBBERROOFS, RUB RUBBERROOFS, RUB RUBBERROOFS, RUB RUBBERROOFS, RUBBERROOFS, RUB	Place pipe seal over the top of the pipe and cut with a knife or scissors to ensure a snug fit.
RUBBERROOFS RUBBERROOFS RUB RUBBERROOFS RUB RUBBERROOFS RUB RUBBERROOFS RUBBERROOFS RUB	Stretch boot over the pipe until the flange touches the deck, mark the perimeter with a crayon or similar, allowing an additional 2cm.
RUBBERROOFS, RUBBERROOFS, RUB RUBBERROOFS, RUB RUBBERROOFS, RUBBERROOFS, RUBBERROOFS, RUBBERROOFS, RUBBERROOFS, RUBBERROOFS, RUB	Fold the pipe boot up or remove and apply primer to the marked area using the quick scrubber pad and handle, allow to dry.
RUBBERROOFS, RUBBERROOFS, RUB RUBBERROOFS, RUB RUBBERROOFS, RUB RUBBERROOFS, RUBBERROOFS, RUB	Reposition pipe seal, locate the join in the release paper and slowly remove at a shallow angle smoothing as you go with your hand. Once the backing paper has been totally removed roller using silicone roller.

