






# Onto Tiles

A guide to installing Lineflex Fleece Backed EPDM membrane onto tiles.

 <p>A 3D perspective diagram showing a grey EPDM membrane being laid over a roof of orange tiles. A dimension line indicates a 150mm overhang of the membrane onto the tiles.</p>	<p><b>Step 1</b> Allow 150mm overhang onto tiles.</p>
 <p>A 3D perspective diagram showing the EPDM membrane being pushed down over the tiles. A lead strip is being inserted under the membrane, with 6 inches of lead on the tiles and 3 inches on the deck.</p>	<p><b>Step 2</b> Dress lead into place 6" onto tiles, 3" onto the deck. We recommend using minimum 9" Code 4 lead cut into 1200mm lengths max.</p>
 <p>A 3D perspective diagram showing a screw being driven through the EPDM membrane into the deck. A circular inset provides a close-up view of the screw.</p>	<p><b>Step 3</b> Fix into position using screws.</p>
 <p>A 3D perspective diagram showing a hand applying a dark primer from a can labeled 'Primer' to the lead and rubber membrane.</p>	<p><b>Step 4</b> Apply Quick Prime plus to lead and rubber approx. 160mm wide using QuickScrubber pad and handle. Allow to go touch dry.</p>



### **Step 5**

Centralize the 6" batten cover strip and carefully remove release paper applying downward pressure. Use a silicone roller to seal.