






## Under Tiles


Step by step guide on installing our Techno EPDM membrane under tiles/sales for your next rubber roofing project.

 A 3D perspective diagram showing a section of a roof. A wooden batten is being lifted away from a row of orange roof tiles. Below the tiles, a grey felt underlay is visible. The background of the diagram is watermarked with the text 'RUBBERROOFS'.	<p><b>Step 1</b> Carefully remove tiles and battens and place to one side.</p>
 A 3D perspective diagram showing the roof section. The grey felt underlay is being folded upwards over the edge of the roof, tucking under the remaining tiles. The background is watermarked with 'RUBBERROOFS'.	<p><b>Step 2</b> Fold the felt underlay up and tuck under existing tiles.</p>
 A 3D perspective diagram showing the roof section. A green rubber membrane is being laid over the folded felt. A white bottle of contact adhesive is shown on the left, with a line indicating its application to the membrane. The background is watermarked with 'RUBBERROOFS'.	<p><b>Step 3</b> Apply a thin coat of contact adhesive to the rubber membrane and lay board.</p>
 A 3D perspective diagram showing the roof section. The green rubber membrane is now being pressed against the underside of the tiles, which are being lifted slightly to show the contact. The background is watermarked with 'RUBBERROOFS'.	<p><b>Step 4</b> Allow both surfaces to dry and, starting from the bottom, mate together, working the rubber into any angle changes.</p>



### **Step 5**

Reinstate the felt underlay and battens over the rubber.



### **Step 6**

Reinstall the tiles.